245380



Power Steering Pump Kit Removal & Installation User Guide

- For quick and easy removal and installation of power steering pump pulleys
- Prevents pulley and shaft from distortion
- Suitable for use ON and OFF vehicle
- Pulley removal, installer and coupler disconnect tool included
- Applications include Ford Falcon FG, Ford C111,
 Saginaw, Thompson, C2 power steering pumps



Warning

- WARNING! Ensure all Health and Safety, local authority and general workshop practice regulations are adhered to when using these tools
- DO NOT use tools if threads are damaged
- Any defective tools MUST be replaced before use
- Maintain the tools in a good, clean condition for optimum performance
- Ensure that a vehicle that has been jacked up is adequately supported with axle stands
- Wear approved eye protection
- Wear suitable clothing to avoid snagging, tie back long hair and **DO NOT** wear iewellery
- Account for all tools, and parts being used and DO NOT leave them in or near the engine

- WARNING! Select neutral or 'park' if automatic transmission and keep hands clear of the rotating engine
- IMPORTANT: Always refer to the vehicle manufacturer's workshop manual, or a proprietary manual, to establish the current procedure and data
- These instructions are provided as a guide only
- When not in use, return all parts in the supplied case and store this in a safe, dry, childproof location
- WARNING! The warnings, cautions and instructions
 referred to in this manual cannot cover all possible
 conditions and situations that may occur. It must be
 understood that common sense and caution are factors
 which cannot be built into this product, but must be
 applied by the operator

Instruction


REMOVAL

NOTE: Always inspect and lubricate threaded parts before using tool to ensure smooth operation

- 1. Select correct forcing screw for removal
- 2. Place jaw enclosure to the pulley and around the pulling flange
- 3. Place retaining ring over the puller jaws to secure them
- Using a wrench tighten the forcing screw while holding the pulling flange nut. This will draw the pulley off the shaft

INSTALLATION

- 1. Select correct forcing screw for installation
- 2. Place pulley over shaft
- 3. Ensure threaded screw is entirely through the centre hole of the shaft
- 4. Using a wrench slowly wind in the flange nut sleeve, forcing the pulley on to the shaft





blob







245380 MAN © Copyright TRIDON AUSTRALIA PTY. LTD. 2017

A.C.N. 001 398 698 Reproduction of this manual in part or full is not permitted without written approval. Illustrations in this manual are for identification purposes only and there may be slight variations between the illustration and actual product. Whilst every effort has been made to ensure that the information contained in this catalogue is accurate at the time of printing, TRIDON AUSTRALIA PTY LTD will not accept responsibility should any inaccuracies be contained herein.