

## 304042A Diesel Injector Puller Adaptor Kit - Application List

Description	Size	Application
Universal joint	M18 x 1.6	Universal
Special bit insert hex	10mm × Ø 7.6	1 x special hex SW10 with 7.6 mm bore, 1/2" drive to remove the fixing ring on Bosch injectors at MB CDI and PSA HDI
Special bit insert hex	10mm × Ø 6.6	Remove the internal screw of the common rail injectors
Pull Spindle	<b>OT</b> M16 × 1.0	Denso injector (Toyota 2.2D)
Pull Spindle	<b>OT</b> M17 × 1.0	Bosch injectors (Alfa, BMW, Fiat, MB, PSA, Renault)
Pull Spindle	<b>OT</b> M20 × 1.0	Denso injectors
Pull Spindle	<b>OT</b> M25 × 1.0	Siemens injectors. Suitable for PSA (DW10) engines Citroen Xsara/Xanita, Peugeot 304/406/206
Pull Spindle	<b>OT</b> M27 × 1.0	Siemens injectors. Suitable for PSA (DW10) engines Citroen Xsara/Xanita, Peugeot 304/406/207
Pull Spindle	<b>IT</b> M14 × 1.5	Internal thread for Bosch / Delphi Injectors MB (OM 629/642/646), PSA (DV4/DW12), VW (CBD), BMW (M47)
Pull Spindle	<b>IT</b> M16 × 1.5	Pull Adapter for M16 x1.5 thread, such as used in Facom tools
Pull Spindle	<b>IT</b> M25 × 0.5	Denso injectors
Pull Spindle	<b>IT</b> M25 × 0.75	Denso injectors
Pull Spindle	<b>IT</b> M27 × 1.0	Siemens, e.g. Citroen C5 / Jumpy / Xsara, Fiat Ducato JTD, Peugeot 206/307/406 / Boxer (2.0 / 2.2 / 2.3 HDI) Mercedes-Benz CDI (except A-Class (Sprinter / Vito)
Special socket	25mm	Siemens Injectors - 2.0 Hdi (DW Series) As found on PSA, Ford, Toyota etc
Special socket	27mm	Siemens Piezo Injectors – 2.0 Hdi Piezo (DW Series) As found on PSA etc
Special socket	29mm	Bosch injectors – Bosch Cdi / Hdi engines
Special socket	30mm	Bosch injectors – Bosch Renault / Nissan 1.9dCi
Injector gripper	12mm	Mercedes-Benz CDI-engines, except Sprinter, Vito and A-class
Injector gripper	13.5mm	GM/Opel, Renault F9Q
Injector gripper	16mm	Fiat Ducato JTD, Citroen C5, Xsara, Jumpy and Jumper HDI and Peugeot 206, 307, 406, Boxer HDI (2.0, 2.2, 2.3l)
Injector gripper	26mm	Opel Z19DT / Z19DTH / Z19DTL engines, A20DTH (LBS) / A20DTR (LBY) / A20DTJ (LBX) / A20DTC (LCD) and Fiat 1.9 JTD

**OT** = outside thread **IT** = inside thread